




B1390AA



B1392AA



B1393AA



Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Handle	B964727NU	1 Set	13	Coupling nut		2 Pcs.
2	Valve G1/2 8x20	B961469NU	1 Pcs.				
3	Body-wall basin		1 Pcs.				
4	Tub.spout R120mm-compl.	B960537AA	1 Set				
4a	Tub.spout J150-compl.	B964966AA	1 Set				
4b	Tub.spout U200mm-compl.	B964734AA	1 Set				
5	Perlator M22x1-B	B964945AA	1 Pcs.				
6	O-Ring Ø13x2.5	B960137NU	1 Pcs.				
7	S-connection compl.		1 Pcs.				
8	S-connections G1/2xG3/4		2 Pcs.				
9	Metallrosette	A963489AA	1 Pcs.				
10	Fibre washer		2 Pcs.				
11	Nipple M19x1.5 LH		2 Pcs.				
12	O-Ring Ø15.6x1.78		2 Pcs.				